


# Lights


**PLEASE TURN OFF ALL LIGHTS WHEN YOU LEAVE THE ROOM.**

## Room Lights



You can turn on/off or dim all the **SPACE** lights at the **touch panel near the deposit door** or at **the controller near the entrance door**. To control them from the touch panel, go under the lamp symbol number 1.



Each row represents a set of lights.



You can turn on/off or dim all the **GALLERIE** lights at the **touch panel near the deposit door** or at **the controller near the entrance door**. To control them from the touch panel, go under the lamp symbol number 2.



You can turn on/off or dim all the **SPOT** lights at the **controller near the entrance door**.

From: <https://wiki.zhdk.ch/IASpace/> - **immersive art space**

Permanent link: [https://wiki.zhdk.ch/IASpace/doku.php?id=hardware\\_lights&rev=1565885624](https://wiki.zhdk.ch/IASpace/doku.php?id=hardware_lights&rev=1565885624)

Last update: **2019/08/15 18:13**



