


# Power

**MAKE SURE ALL POWER CABLES AT WAK BOXES ARE PLUGGED IN THE LOWEST SOCKET.**

WAK 1 - 6 are in the lower level of the IASpace. WAK 7 - 12 are in the middle level of the IASpace and WAK 13 - 18 are in the upper level of the IASpace (some WAK may be behind the black curtains).

**In order to access the WAK page from the control page, you need to be login as Admin.** (Please refer to this page).



## Powering ON computers

Turn on the computers by pressing the button with the "Alien".



From:  
<https://wiki.zhdk.ch/IASpace/> - **immersive art space**

Permanent link:  
[https://wiki.zhdk.ch/IASpace/doku.php?id=hardware\\_power&rev=1565885937](https://wiki.zhdk.ch/IASpace/doku.php?id=hardware_power&rev=1565885937)

Last update: **2019/08/15 18:18**

