
OptiTrack MoCap Cameras

To power up the OptiTrack MoCap system, follow this procedure:


- Navigate to the Home page on the touch panel in the back corner of the room




- Login as `Admin` (password can be found inside of key lockbox above the touch panel)




- Navigate to the AV page



- Toggle the power controls `Nr. 13 -> Manuell -> I/O` & `Nr. 15 -> Manuell -> I/O` to the on (green) setting in the for WAK Galerien Gessneralle (Ost) section.



- After starting he OptiTrack software on the Alienware computer, the rings on the face of the cameras should light up
- When finished, be sure to turn `Nr. 13` & `Nr. 15` back to the off (red) setting
- Logout from the system (if it has not already automatically timed out)



From:
https://wiki.zhdk.ch/IASpace/ - **immersive art space**

Permanent link:
https://wiki.zhdk.ch/IASpace/doku.php?id=optitrack_camera_system&rev=1565884079

Last update: **2019/08/15 17:47**