Motive_Calibrating

When you start motive you should see the following:

×

if not, go to menu > layout > callibrate

First you have to make sure no reflective objects are visible to the system.

Ideally it should look like this:

×

The only big refelections ara actually the cameras. everything else that reflects should be removed.

Many shoes have actually reflective surfaces, so make sure to either tape them or take them off for the following processes.

switch between the video modes to identify reflections:

×

×

once all the refelctions are removed, clear the previsouly set masks (press "Clear Mask"):

×

switch back the video mode to tracking mode.

×

check the Tracking Parameters

×

ideal settings are:

- FPS: 100
- EXP: 55
- THR: 200
- LED: 15

adjust this values until the reflections from the floor are acceptable.

then set the masks again (press "Mask visible"). it is important that nobody is inside the space at this moment.

×

once the masks are set, the space is ready for wanding. make sure you are using the correct wand (500mm)

×

keep on wanding until each camera has at least 1500 Samples:

×

press calcualate:

×

once the result looks like this:

×

confirm to apply:

×

and as the last step set the ground plane. The ground plane L has a defect waterbalance, so please do not adjust the leveling screws, it should be ok the way it is now.

×

the ground plane Z-Axis should point towards the computers. there are three markers on the trackingspace that indicate the position. If you plan to use the tracking system with projections, take special care to position the groundplane as precise as possible over the markers.

save the callibration file inside your session folder.

×

From: https://wiki.zhdk.ch/IASpace/ - **immersive art space**

Permanent link: https://wiki.zhdk.ch/IASpace/doku.php?id=motive_calibrating&rev=1522158871

Last update: 2018/03/27 15:54

